

Bluetooth device mode

- 1: In general, if you don't plug the SD card into board, it will be set as bluetooth device mode, and you can connect it with your other device easily. When you connect successful, your device's audio files can be controlled to play by this board.(it has voice tip so you can
- 2: You also can press the mode button to decide which mode you want to use.